



CRUMPLER

GEAR FOR
URBAN
EXPLORERS



PHOTO COLLECTION

2013

QUICK ESCAPE

COLLECTION


Highly functional, minimalist, top-loading photo bags
allowing ultra-fast access to your equipment




QUICK ESCAPE COLLECTION

size	outside (in cm)	inside (in cm)	weight (in kg)	
150	17x18.5x12	11x16x7.5	0.25	+ Raincover
300	20x20.5x12	13x17x9.5	0.31	+ Raincover
400	20x23x12.5	13x20x9.5	0.33	+ Raincover
600	25x20x14.5	20x16.5x9.5	0.59	+ Raincover
700	29x23x18	25x18.5x10.5	0.69	+ Raincover
800	26x30x13	24.5x28.5x12.5	0.70	+ Raincover
Sling	27x43x17	22x33x12.5	0.94	+ Raincover


available in 3 colours:




Quick Escape 150



Quick Escape 300




Quick Escape 400




Quick Escape 600



Quick Escape 700



Quick Escape 800



Quick Escape Sling



Integrated rain cover

Padded adjustable dividers for
extra flexibility and
ease of handling

Waterproof Ripstop Lining
and soft protective interior



Large, ergonomic,
across-the-body padded
shoulder strap with single hand
length-adjustment






LIGHT DELIGHT

PHOTO COLLECTION

Structured featherweight bags
designed specifically for cameras



Light Delight 400




Light Delight 600



Light Delight 700



Light Delight 2500



Light Delight 4000



Light Delight 6000



Light Delight Foldable Backpack



LIGHT DELIGHT PHOTO COLLECTION

name	size	inside (in cm)	weight (in kg)
Hipster	400	21x14.5x9	0.29
	600	28x17x9.5	0.43
	700	31x19x11.5	0.47
Sling	2500	20x15x8.5	0.18
	4000	27x18x11.5	0.31
	6000	32x20x13.5	0.43
Backpack	Foldable Backpack	15.5x25.5x10	0.69

available in 5 colours:






Zip-fastened camera compartment

Internal quilting and padding for protection

Backpack folds away to Hipster sized camera bag

Strong and lightweight adjustable shoulder straps

Padded side extensions to provide better load distribution and comfort




Waterproof Ripstop lining

THE PROTECTION COLLECTION

Innovative storage and protection solutions. Perfect for when you want your photo gear with you, but not your photo bag








Super soft & shiny Neoprene with
water & dust repellent Moses Effect coating

PROTECTION COLLECTION

name	size	outside (in cm)	inside (in cm)	weight (in kg)
The P.P.	40	11.5x7.5x3.5	10x6x2	0.08
	55	12.5x7.5x4	11x6x2.5	0.08
	70	11x8x4.5	9.5x6.5x3	0.09
	90	12x8x4.5	10.5x6.5x3	0.09
Banana Cube	S	17x14.5x9	15.5x12x7.5	
	M	19x16.5x10	17.5x13.5x9	
Banana Bowl	S	19.5x16x11.5	17.5x13x9.5	0.21
	M	26.5x21x13	25x17.5x11	0.37
Banana Hammock	S	14.5x16.5x11	13x15x9.5	0.15
	M	17x20x13	15.5x18.5x11.5	0.18
	M-Zoom	17x23x13	15.5x21.5x11.5	0.20
Singapore Sling		139x7.5x1		0.10

available in 3 colours:



The P.P.



Banana Cube



Banana Bowl



Banana Hammock



Singapore Sling



Zip-fastened main compartment with internal binding to protect camera from scratching

Internal waterproof Ripstop lined slip pocket on lid

Carry handle

Padded adjustable dividers for extra flexibility





JACKPACK

PHOTO

COLLECTION

Camera pouches, sling bags and backpacks
for the urban outdoors



JACKPACK PHOTO COLLECTION

available in 3 colours:



name	size	outside (in cm)	weight (in kg)
Pouch	40	8.2x12x4	0.06
	70	8.7x12.7x5	0.07
	90	9.5x13.5x5	0.07
Sling	1500	21x17.5x10.5	0.26
	3000	28x20x11.5	0.44
	4000	30x20.5x12.5	0.55
	5500	35x21x15	0.80
	7500	34x23.5x16.5	0.69
Backpack	Half Photo System Backpack	27x38.5x16	0.81
	Half Photo Backpack	33.5x45.5x20.5	1.28
	Full Photo Backpack	28x45x14.5	1.31



Jackpack Photo Pouch 40, 70, 90



Jackpack Photo Sling 1500, 3000, 4000





Internal iPad / laptop
compartment with
Velcro tongue closure

Side compression straps
to adjust the depth of the bag
for better carrying comfort


Strong adjustable shoulder
straps with loops for
accessory attachment

Clip and drawstring-fastened
main compartment

Fixed, padded
camera compartment







CRUMPLER STORES

BERLIN KREUZBERG

Nostizstr. 23
10961 Berlin
+49 (0) 306 950 43 40

BERLIN ALEXA

Grunerstr. 20
10179 Berlin
+49 (0) 309 560 39 23

ONLINE SHOP
www.crumpler.eu

BREMEN

Vor dem Steintor 36
28203 Bremen
+49 (0) 421 790 10 87

HAMBURG

Schanzenstr.83
20357 Hamburg
+49 (0) 404 309 21 30

KÖLN

Ehrenstr. 71
50672 Köln
+49 (0) 221 258 94 04

AMSTERDAM

Haarlemmerdijk 31
1013 KA Amsterdam
+31 (0) 20 620 2454

ROTTERDAM

Nieuwe Binneweg 1/n
3014 GA Rotterdam
+31 (0) 10 225 1370

UTRECHT

Oudegracht 210
3511 NS Utrecht
+31 (0) 30 240 0630



Removable
Shoulder
Strap



Space
for
Accessories



Memory Card
Pocket



Rain
Cover



Fits
iPad



Chicken
Tex
Supreme™



Flexible
Neoprene



For
DSLR
Cameras



For
Compact
Cameras



Fits
Laptop
Sleeve



For
System
Cameras